

Tools Required: none

Parts Included: none

Pre Installation

- 1) Carefully read and follow instructions to ensure optimal performance.
- 2) Thoroughly wash & wax vehicle surfaces to prevent entrapment of moisture and/or debris between paint finish and the *SpeedLingerie™*.

Rear Deck Cover Installation – to protect the top and rear of the rear fascia while loading cargo in/out of the trunk

- 1) Open the rear deck lid.
- 2) Orient the *SpeedLingerie™* with the notched side 'up', and the felt side 'in'.
- 3) Slip the tension cord over the cargo net pins.
- 4) Let the *SpeedLingerie™* drape over the top the rear deck, and down the rear end of the vehicle.
- 5) You can now load items in/out of the trunk – and protect your paint finish.
- 6) To store the *SpeedLingerie™* with an empty trunk, roll it up from the bottom (felt side out), leave the tension cord hooked over the factory cargo net pins, and lay it inside the truck area just in front of the cargo net.
- 7) To store the *SpeedLingerie™* with the trunk fully loaded, flip it on top of the load with the felt side up – and protect the inside of your hatchback lid.
- 8) Close the rear deck lid.

Cargo Cover Installation – to cover cargo stored in the trunk area.

- 1) Open the rear deck lid.
- 2) Lay the *SpeedLingerie™* over cargo stored in the trunk area.
- 3) Applies more to the convertible Corvette – protects cargo from the sun and by keeping it out of sight.

Trunk Mat Installation – to protect the trunk carpeting from dirt

- 4) Open the rear deck lid.
- 5) Lay the *SpeedLingerie™* flat on the floor of the trunk area.
- 6) You can now load items into the trunk – and protect your carpeting.

Door Cover Installation – to protect the driver's door from nicks and dings in the garage or parking lot

- 1) Open the driver door.
- 2) Orient the *SpeedLingerie™* with the notched side 'up' (to conform to the outside door mirror).
- 3) With the door window up, slip the tension cord over the glass.
- 4) Pull down on the *SpeedLingerie™*, and slip the notched edge of the *SpeedLingerie™* under the outside door mirror.
- 5) Adjust the *SpeedLingerie™* so it hangs evenly.
- 6) Shut the door (the tension cord will be locked inside the door to prevent theft of the *SpeedLingerie™*).
- 7) You can now park two cars in your garage, or in a parking lot – and protect your door from dings.

Front Fender Cover Installation – to protect the fender while working in the engine compartment.

- 1) Open the hood.
- 2) Orient the *SpeedLingerie™* with the two loops 'up', and the felt side 'in'.
- 3) Attach the front loop over the hood hinge, near the headlight assy.
- 4) Attach the rear loop over the windshield wiper arm, near the base of the windshield.
- 5) Adjust the *SpeedLingerie™* so it hangs evenly.
- 6) You can now reach into the engine compartment – and protect your fender from scratches

Continued next page

Care & Maintenance

1. For best results, vehicle surfaces must be washed and waxed, to ensure they are clean and dry before installing *SpeedLingerie™*
2. Always inspect *SpeedLingerie™* fasteners and surfaces that contact vehicle for possible debris, sand, grit, etc and remove before installation (see step #7).
3. Periodically remove to allow complete aeration of vehicle paint finish and *SpeedLingerie™* materials.
4. Remove *SpeedLingerie™* before washing vehicle.
5. Remove *SpeedLingerie™* after exposure to rain or other fluids/moisture.
6. Clean outer vinyl surfaces of *SpeedLingerie™* with a high quality vinyl conditioner during routine car maintenance.
7. Clean felt inner surface with a shop vacuum (or shake it out) to remove any particles. If the inside it is *very* muddy or dirty, use low pressure fresh clean water to rinse it out and allow it to dry completely.
8. Rubber will stain vinyl. DO NOT store your *SpeedLingerie™* in direct contact with any rubber products (tires, hoses, etc) as vinyl is a very porous material and will absorb the black carbon in rubber products, resulting in a stain.

Congratulations on your purchase. Enjoy that Corvette!

For installation questions call 650-964-2584 or email us at info@speedlingerie.com.